

LIST OF PARTS  
MACHINE NO. 107W53

\*210501 Arm with 202135  
 203087 " Cap  
 200278X " " Screw  
 202248 " " " Washer  
 203089 " " Spool Holder Base  
 203090 " " " " " 203089 with 200079X and 204296  
 200585X " " " " " Screw  
 204296 " " " " " Wire  
 200079X " " " " " Hinge Screw  
 203088 Arm Cap and Spool Holder complete, Nos. 203087, 203090, and two 200585X  
 204235 " Position Pin (2)  
 200010E " Screw (3)  
 202005 " " Washer (3)  
 202249 " Shaft with 224392  
 240802 " " Bushing (back) with 202244  
 202244 " " " " Oil Packing (wick)  
 200338C " " " " Set Screw  
 207080 " " " (front) with 202244  
 202244 " " " " Oil Packing (wick)  
 200502X " " " " " " Thumb Screw  
 200341C " " " " Set Screw  
 224400 " " Connection Belt (reinforced neoprene)  
 202635 " " " " Pulley with 200327C, 200602C, and two 202253  
 200602C " " " " Pulley Position Screw  
 200327C " " " " " Set Screw  
 202253 " " " " " Spring Flange  
 224392 " " Oil Packing (wick)  
 \*242001 Bed (cylinder)

MACHINE NO. 107w53

213890 Bed Base (4 inches high)  
NOTE: Bed Base 213890 is furnished with this machine unless  
otherwise specified on order

213353 Bed Base (6 inches high)

203184 " Clamp

200262X " " Hinge Screw

202622 " " Packing Washer

200728X " " Thumb Screw

203185 " " " " Washer

202618 " Hinge

201110X " " Screw (6)

210505 " Plate (back)

200577AL " " " Screw (2)

263099 Bobbin

210846 " Case Base

224440 " " Cap with 200592C, 201016C and 263110

224441 Bobbin Case Cap complete, Nos. 200964C, 210736, 210914 and 224440

210913 " " Latch

210914 " " " 210913 with 210734 and 210735

210735 " " " Fulcrum Pin

210734 " " " Lever

210736 " " " Spring

200964C " " " Stop Screw

242002 " " Stop

200126D " " " Screw

263110 " " Tension Spring

201016C " " " " Regulating Screw

200592C " " " " Screw

224442 Bobbin Case complete, Nos. 210846 and 224441

MACHINE NO. 107\*53

242003 Cylinder End Cover with 242004 and two 200177D  
200294X " " " Hinge Screw (2)  
242004 " " " Latch  
200177D " " " " Screw  
210681 Face Plate  
202135 " " Position Pin  
200462X " " Thumb Screw  
210682 Face Plate complete, Nos. 210681, 210684 and two 200137X  
— 242005 Feed Bar  
242006 " " 242005 with 200641C, 201522E and 202623  
200641C " " Hinge Screw (driving)  
201522E " " " " Nut  
- 202276 " " Slide Block  
202624 " " " " Crank with 200038C  
— 242008 " " " " " 202624 with 200205F, 201518E and 202276  
200038C " " " " " Pinch Screw  
200205F " " " " " Hinge Screw  
201518E " " " " " " Nut  
242018 " Dog, for 210603  
200106E " " Screw (2)  
202297 " Driving Connection with 200054E and 203101  
242022 " " " " Crank with 200038C  
200038C " " " " " Pinch Screw  
200545C " " " " " Hinge Screw  
201518E " " " " " " Nut  
203101 " " " " " Oil Packing (wick)  
200054E " " " " " Pinch Screw  
202300 " " " Eccentric Regulating Bracket

MACHINE NO. 107453

203098	Feed Driving Eccentric	Regulating Bracket	202300 with 202635, two each 201014C and 201525E
201014C	"	"	Regulating Bracket Hinge Screw
201525E	"	"	" " " Nut
202301	"	"	" " Plunger
202595	"	"	" " Spring
200607C	"	"	" " Stop Screw
201014C	"	"	Regulating Bracket Stop Screw
201525E	"	"	" " " Nut
200429F	"	"	" " Screw
200383C	"	"	" " Check Screw
202623	"	"	Rock Shaft
202625	"	"	" " Stop Collar with two 200383C (2)
200383C	"	"	" " " Set Screw
202306	"	"	Lifting Connection with 200054E and 203101
*210645	"	"	" Crank
210589	"	"	" " 210645 with 200050C and 200378C
200050C	"	"	" " Pinch Screw
200378C	"	"	" " Set Screw
202307	"	"	" " Eccentric with 200382ALX and 200437C
200437C	"	"	" " Position Screw
200382ALX	"	"	" " Set Screw
200545C	"	"	" " Hinge Screw
201518E	"	"	" " " Nut
203101	"	"	" " Oil Packing (wick)
200054E	"	"	" " Pinch Screw
210531	"	"	Rock Shaft (hollow) and Hook Driving Shaft Bear- ing
202625	"	"	" " Stop Collar with two 200383C

MACHINE NO. 107W53

200333C Food Lifting Rock Shaft Stop Collar Set Screw  
200310 " Regulating Spindle with 202311, 202443 and 202619  
\*202311 " " " Head  
202443 " " " " Pin  
202619 " " " " Position Pin  
224432 Hook (sewing) with 203101 and ~~263134~~ 502535  
224433 " 224432 with 2001L50, 210536, 210541 and three 200596F  
224443 Hook and Bobbin Case complete, Nos. 224433 and 224442  
210614 " Driving Bevel Pinion (steel), 24 teeth, with two 200378C  
200378C " " " " Set Screw  
210535 " " " " Shaft  
202661 " " " " " Belt Pulley with 202324 and  
two 200378C  
200378C " " " " " Shaft Belt Pulley Set Screw  
202324 " " " " " " " Spring Flange  
210536 " Gib  
200596F " " Screw  
535-~~263134~~ " Oiling Felt  
203101 " Oil Wick  
350984F " Position Screw  
242011 " Shaft (hollow)  
210615 " " Bevel Gear (steel), 24 teeth, with two 200382ALX  
200382ALX " " " " Set Screw  
242020 " " Bushing with 265683  
242012 " " " 242020 with 200931F and 242011  
265683 " " " Oil Packing (wick)  
0363AL-~~201007C~~ " " " Set Screw  
244084 " " " " " packing (fibre)  
200931F " " Position Screw

MACHINE NO. 107W53

210541	Hook Washer	Needle Guard
2001450	"	" " " " Screw
242009	Knee Lifter	Lifting Lever
200242X	"	" " " " Hinge Screw
242010	"	" " " " Rod with 202302
202302	"	" " " " Cotter Pin
233361	"	" " " " Spring
200273D	"	" " " " Screw
233390	"	" " " " Washer
244090	Machine Pulley (disc)	(aluminum alloy casting) "V" belt groove (outside diam. of belt groove 2.9 in.) with <del>3505406</del> and <del>3505410</del> <i>141566C</i> <i>141567C</i>
<del>440 3505406</del>	"	" " Position Screw
<del>507C 3505410</del>	"	" " Set Screw
224317	Needle Bar	with 200125ALX, 200175X and 249270
210543	"	" " Connecting Link
202333	"	" " " " Stud with 202299
202299	"	" " " " Oil Packing (wick)
200383C	"	" " " " Set Screw
200374AL	"	" " " " " " "
210544	"	" " " " Stud with 202299
210585	"	" " " " 210544 with 210882
202299	"	" " " " Oil Packing (wick)
210882	"	" " " " Swivel with 200387C
210725	"	" " Crank with 200335C, 200374AL, 200383C, <sup>200432C</sup> <del>200428C</del> and 202333
203172	"	" " " " Friction Washer
<del>0432C 200428C</del>	"	" " " " Position Screw
200335C	"	" " " " Set Screw
200388C	"	" " " " LOCK SCREW <i>20</i>





200607C	Needle Vibrator Eccentric	Regulating Bracket Plunger Spring	Stop Screw
2002560	"	"	" " " " " " Nut
201525E	"	"	" " " " " " " " Nut
210699	"	"	Gear (spiral) with two 200382ALX
203172	"	"	" Friction Washer
200382ALX	"	"	" Set Screw
210558	"	"	" Shaft
210559	"	"	" " Collar with two 200378C
200378C	"	"	" " " " Set Screw
210700	"	"	Pinion (spiral) with two 200382ALX
200382ALX	"	"	" Set Screw
200429F	"	"	Regulating Screw
200383C	"	"	" " Check Screw
233175	"	"	" Spindle with 210554
210554	"	"	" " Spring (flat)
244033	Presser Bar	(hollow)	
202335	"	"	244033 with 200074F
207072	"	"	Bushing
200352AL	"	"	" Set Screw
202554	"	"	Lifter
200653C	"	"	" Hinge Screw
210789	"	"	Lifting Releasing Lever Bracket
200260E	"	"	" " " " " " Guide Screw
206608	"	"	" " " " " " Spring
202337	"	"	Position Guide
202338	"	"	" " Lever with 200086ALX
200086ALX	"	"	" " Pinch Screw
200352AL	"	"	" Set Screw

202343	Presser Bar Spring
202346	" " " Stop Rod
200492X	" " Thumb Screw (pressure regulating)
200475X	" " " " Thumb Set Screw
244084	" " " " " " " Packing (fibre)
242053	" Foot Edge Guide
200175X	" " " " Screw
230795	" " Hinge Pin
242054	" " Plate
200074F	" " Screw
202923	" " Shank
242055	Presser Foot (hinged) complete, Nos. 200175X, 202923, 230795, 242053 and 242054
210591	Take-up (auxiliary), for Swivel
200132E	" " Screw
244059	" Lever
202399	" " Driving Stud with 244071
244071	" " " " Oil Packing (wick)
202400	" " Hinge Stud with 202423
202423	" " " " Oil Packing (wick)
200383C	" " " " Set Screw
202401	" " Oiling Felt
200132E	" " " " Screw
244048	Tension Disc (back)
244049	" " (front)
202404	" Release Plunger
244061	" " Washer
223438	" Spring
263106	" " Washer

MACHINE NO. 107w53

200625F Tension Stud with 204925  
200061ALX " " Set Screw  
204925 " " Washer  
201572X " Thumb Nut  
244662 Tension complete, Nos. 200625F, 201572X, 202410, 223438, 244048,  
244049, 244061 and 263106  
202410 Thread Controller Spring  
241443 " " " Stop  
200132E " " " " Screw  
210593 " Guide (lower)  
202412 " " (on top of Arm)  
210592 " " (upper)  
200582X " " Screw (2)  
240335 " Retainer  
210683 " " Bracket with 200397X  
200137X " " " Screw  
200368X " " Set Screw  
210993 " " Sleeve  
210992 " " Spring  
210957 " " Stud  
210958 " " " Collar  
200397X " " " Set Screw  
210684 Thread Retainer Bracket complete, Nos. 210683, 210957, 210958,  
210992 and 210993  
210693 Throat Plate, 53 needle hole, for needle sizes 12 and 13, for  
242018  
200577AL " " Screw (2)

ACCESSORIES

200157X	Attachment Screw
263099	Bobbin (2)
259462	Bobbin Winder
203058	Knee Lifter Lifting Lever Rock Coupling
228251	Knee Lifter Rock Shaft complete
51078	Machine Bolt (4)
6055	Machine Bolt Washer (4)
41401	Machine Rest Pin
135x5	Needles #14 (6)
120342	Oil Can
225498	Screw Driver
228476	Screw Driver (Bobbin Case)
242017	Work Plate
201011X	Work Plate Screw (back)
200577AL	Work Plate Screw (front)(2)
225554	Wrench