

**SINGER**  
**410W110**

Form 3026w  
(350)  
Printed in U. S. A.

# SINGER\*\*

## 410w110




\*\* A TRADE MARK OF


THE SINGER MANUFACTURING COMPANY

18280 - 1/2




Copyright, U. S. A., 1941, 1942, 1946 and 1950  
by The Singer Manufacturing Co.  
All Rights Reserved for all Countries






18286


18332 - 3/8





18333 - 1/4




18454 - 1/2





18457 - 1/2



18458 - 3/8

